


WTF!
WORKSHOP
#1

WHEELS

(of FORTUNE!)



TIRE → (TUBE INSIDE)

RIM
HUB

SPOKES

Some ALTERNATIVE
BITS

CAGED
BALANCEBINGS

AXLE

flange

Loose
BALL BEARINGS




NUT

cone


Locknut

BASIC
BITS

HUB



THIS IS
CALLED AN
"EXPLODED
DIAGRAM" *



BEARINGS SIT
IN A BOUNDED CUP
INSIDE HUB,
CALLED A
RACE.

SIDEVIEW OF
HUB

THREADS are the
spiral thingy nuts
screw onto


SPOKE

NIPPLE

Bearings are
inside case




BIA!



Spoke is inside
case



THE MOST IMPORTANT STUFF ABOUT WHEELS:



ON REAR WHEELS, YOU GENERALLY NEED TO REMOVE THE COGSET TO GET THE AXLE OUT. YOU ALWAYS HAVE TO REMOVE IT TO REPLACE SPOKES.

YOUR WHEEL WILL ROLL WELL IF...

① YOUR PARTS ARE SMOOTH

② YOUR PARTS ARE CLEANED & GREASED THOROUGHLY.

③ YOU ADJUST IT JUST RIGHT

④ YOU TIGHTEN THE CONE & LOCKNUT AGAINST EACH OTHER, LOCKING THEM IN PLACE.

& POORLY IF...

YOUR BEARINGS, RACES OR CONES ARE PITTED.

YOU'RE UNDERGREASED OR LADEN WITH GRIT

IT'S A LITTLE TOO TIGHT (RESISTS ROLLING) OR LOOSE (AXLE WOBBLIES IN HUB)

THEY CAN MOVE AROUND & LOSEN YOUR HUB.

WHAT HAPPENS IF...

THE HUB'S TOO LOOSE? → • SMASHES BEARING CAGE & WEEKS BEARINGS ETC.
• LETS GRIT IN, PITTING BEARINGS ETC.
• BENDS AXLE
• OH, POOP.

I OVER-GREASE? → NO SUCH THING.

IT'S DIRTY, IN THERE? → • IT'LL GRIND. EVEN WHEN ADJUSTED RIGHT.



• YOU'LL HAVE TO CLEAN IT AGAIN

Pieces are pitted? → • GRINDING! → MORE PITTING.
• YOU'LL HAVE TO REPLACE THE PART

WHEN REPLACING ANY PART: CHECK FOR SIZE (WIDTH, LENGTH, HOLE DIAMETER ETC.), THREADING-COMPATABILITY, SMOOTHNESS OF SURFACE / DAMAGE TO THREADS, EDGES (OF NUTS), & BEARING-CONTACT SITES, & BILATERAL SYMMETRY ACROSS THE HUB

IF REPLACING A SPOKE, METICULOUSLY FOLLOW LACING PATTERN





TOOLS INVOLVED:



*COGS ARE GOING TO GET TACKED DOWN WITH DERAILLEURS & GEARS

WTF
Workshop
2

BRAKES!




A WORD ON SPRINGS

all ^{normal} brakes require springs to work. The springs push the arms back to their original position, open. Brake bosses often have multiple holes to allow you to reposition the spring.





WTW
Workshop
2

V-BRAKES



(SIDE VIEW)




CALIPERS need to be centered. it's all about adjusting the bolt that holds it to your frame: overtightened, it will be cockeyed, and under-tightened, it will wobble & not brake well.

FRONT OR REAR?

front brakes just have a
~~LONGER BOLT~~
to go thru the fork.


they take a concave
washer to be sturdy on
your round frame




CABLES & HOUSING

WHAT IS HOUSING FOR?

it allows the linear force of your brake lever to go around curves, & receives the cables' "equal & opposite" force to the lever.



FERRULES



are these little metal housing-tips. you only need them where the housing doesn't fit snuggly in the cable stop.

★ SIDE PULLS & ~~center~~ BRAKES DON'T REQUIRE CABLE-DANGLING DEVICES, BUT CANTIS & CENTER PULLS DO.

bolt-on cable guides

often it's a KEY-WAY WASHER on the headset

Brazed-on cable guides


Brazed-on cable stop

WHERE DO I PUT THE CABLE? → the bike will give you

hints: if this is the frame, on top you'll see some structures that direct the cable.


Sheldon Brown's four COMMANDMENTS of CABLE ROUTING:

1. Allows handlebars their full range of motion (does not limit turning.)
2. Curves shouldn't make wrong-way bends, as in:
3. All curves should be as wide as possible:
4. Make housing as short as possible without violating the above rules.



WTF
workshop

TOP FIVE REASONS WHY YOUR BRAKES SUCK:

1. Poor friction due to buildup of crap on your rims or pads: try filing the surface of your brakepad & cleaning your rim.
2. They're poorly aligned:

3. They're too loose: You can tighten them using your barrel adjuster for only so long before you have to loosen the nut holding your cable, squeeze your brakes together, pull the cable tight & re-secure the cable in there. Make sure to put barrel adjuster in middle position first!
4. If the brakearms don't open up again after you brake, you're probably got excessive friction in your housing. Sometimes it works to clean & lube it, but if it's too corroded you might just have to replace the housing entirely.
5. Your brakearms are asymmetrical: one pad contacts the rim before the other, making it squeaky & not effective at braking.

TOOLS FOR BRAKE ADJUSTMENT:

